

FM18-1A

PARTS LIST

ITEM	PART NUMBER	DESCRIPTION	QTY
01	219-D322	MACHINED BODY	1
02	68-407	STRAIGHT CONNECTOR	2
03	80-160	BRASS PLUG	2
04	43-A264	HIGH SPEED NEEDLE	1
05	24-B449	ADJUSTMENT SCREW SPRING	2
06	44-270	O'RING	1
07	78-A256	ADJUSTMENT SCREW WASHER	1
08	36-A42	* INLET SEAT	1
09	34-216	* INLET NEEDLE	1
10	49-B31	REMOTE FIXED JET VARIOUS	1
11	15-C159	THROTTLE CABLE ATTACHMENT	1
12	14-A139	THROTTLE SLIDE VARIOUS	1
13	32-508	FULCRUM PIN	1
14	16-B524	GASKET FLOAT BOWL	1
15	91-B433	SLIDE CAP	1
16	30-788	CLEAR PLASTIC FLOAT BOWL	1
17	30-789	FLOAT - 4 gr MINIMUM WEIGHT	1
18	47-A293	NOZZLE MAIN FUEL	1
19	47-A294	MAIN NOZZLE TUBE VARIOUS	1
20	24-C371	THROTTLE SLIDE SPRING	1
21	49-B170	IDLE JET VARIOUS	1
22	34-549	SLIDE NEEDLE VARIOUS	1
23	29-260	CIRCLIP SLIDE NEEDLE	1
24	18-A100	BARREL GUIDE	1
25	49-B185	MAIN JET VARIOUS	1
26	68-A537	M6x1, 3/16 BARB CONNECTOR, BRASS	1
27	16-B199	* COPPER GASKET, INLET SEAT	1
28	78-A377	WASHER COPPER	1
29	44-401	O-RING - SLIDE CAP	1
30	81-832	CABLE GUIDE NUT	1
31	15-C160	CABLE GUIDE -	1
32	102-251	SLEEVE CABLE GUIDE	1
33	15-C161	SCREW	4
34	813-38	OVERFLOW TUBE	1
35	15-C154	IDLE SPEED ADJ. SCREW	1

IDLE JET:

0.54mm > 49-B167
 0.57mm > 49-B168
 0.60mm > 49-B169
 0.63mm > 49-B170
 0.66mm > 49-B171
 0.69mm > 49-B173

MAIN JET:

0.48 > 49-B180
 0.51 > 49-B181
 0.54 > 49-B182
 0.57 > 49-B183
 0.60 > 49-B184
 0.63 > 49-B185
 0.66 > 49-B186
 0.69 > 49-B187
 0.72 > 49-B188

